VORTEX DUO

Quick Feature Reference

WEB TOOLS & RESOURCES

Useful Links Be sure to visit these

- Click **titles** in this document for Wiki!
- `lightshow.lol` – Build Modes
- `vortex.community` – Share Modes
- Find our discord on the `Wiki`!

BASIC OPERATION

Interface How to interact with the Duo

- All **SHORT** or **LONG** (250ms) clicks
- Rare to **HOLD** the button
- Designed to reduce waiting around

Primary Control Main Features

- **Turn ON**: **SHORT** click from OFF
- **Turn OFF**: **LONG** click from ON
- **Access Menus**: **HOLD** till white
- **Conjure Mode**: **LONG** click from OFF
- **Light Lock**: 5x **SHORT** from OFF
- **Force Sleep** / **Panic Exit**: **HOLD** 10s

SELECTING MENUS & LEDS

Menus Edit mode or device settings

- In order of usefulness!
- Affect current mode:
  - ● Randomizer
  - ● Mode Sharing
  - ● Color Select
  - ● Pattern Select
- Affect entire device:
  - ● Global Brightness
  - ● Factory Reset
- Quick exit: enter randomizer then exit

LED Selection ●● Pick target LED

- Some menus require LED selection
- Choose the affected LED(s)
- **SHORT**: Cycle: tip, top, or both
- **LONG**: Confirm selection

MENU OPERATION

Randomizer Roll new modes

- ●● Select LED first
- **SHORT**: randomize new mode
- **LONG**: save & exit
- **SHORT** 3x: Enable auto random

Mode Sharing Wirelessly share

- **SHORT** to cycle options
  - ● Modern: **HOLD** to send
  - ● Legacy: **LONG** to send
  - ● Exit: **LONG** to leave

Color Select ●●●●●● Edit mode colors

- ●● Select LED first
- Pick slot:
  - Existing = edit, empty = add
  - exit = shows colors + red on top
  - HOLD on slot: delete
- For slot:
  - **Pick hue quadrant:**
  - **Pick fine hue:**
  - **Adjust saturation:**
  - **Adjust brightness:**
  - Returns to slot select
  - Repeat or exit

Pattern Select Edit mode pattern

- ●● Select LED first
- **SHORT**: next pattern
- **LONG**: confirm/exit

Brightness Adjust brightness

- **SHORT**: Pick Brightness
- **LONG**: Save & exit

Factory Reset Reset device

- **SHORT**: Pick cancel or reset
  - Cancel: Exit factory reset
  - Reset: HOLD until solid white